Made in China

Distributed by InvenTel Products, LLC
200 Forge Way, Suite 1, Rockaway, NJ 07866
www.InvenTel.tv

InvenTel Products, LLC. Reserves the right to provide you with the newest product available to date.
Engineering enhancements are ongoing and may not be reflected in the pictures and specifications on this package.

Product color and appearance may vary from that shown on packaging.
2018 InvenTel Products, LLC. All Rights Reserved.

MAGIC stitch

ELECTRIC SCISSORS

USER'S GUIDE

Version 1

©2020 Inventel Products, LLC. All rights reserved.

Enjoy arts and crafts!

These easy-to-use switch-adapted scissors allow you to participate in art and other classroom or home activities. Just activate your switch and your scissors will easily cut through paper. Easy to remove from special mounting. Base size: 6"L x 8"W x 2"H. Scissor size: 10¼"L x 5"H. Requires Capability Switch and 2 AA Batteries. Weight: 1¼ lbs.

Operation:

1. Scissors requires 2 AA batteries. Use alkaline batteries only. Do not use rechargeable, heavy duty or any other type of batteries as they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types. Follow the installation diagram below.

2. To install the AA batteries, you must carefully pull the bottom handle of the scissors down to reveal the battery compartment. Once the compartment is open, install the batteries paying close attention to proper (+) and (-) polarity. Place battery cover back into the base as shown in the photo here and additional photos on the back page of this guide.

3. Activate your switch and the scissors will run for as long as your switch is activated, once you release your switch the scissors will stop.

Troubleshooting:

Problem: The scissors do not activate.

Action #1: Make sure that all batteries are installed following proper (+) and (-) polarity. Batteries must be fresh, if weak or dead replace.

Action #2: Make sure that the disk is seated flat against the (-) side of the battery it comes in contact with, as described in operation No.1.

Care of Unit:

The scissors can be wiped clean with any mild household multipurpose, non-abrasive cleaner and disinfectant.

Do not submerge the unit in any fluids, as it will damage the contents and the electrical components.

Do not use abrasive cleaners, as they will scratch the surface of the unit.