



Operating Manual

Please read the contents of this manual before use.



Failure to use properly may result in the damage of the product.

WARNING: This product is not a toy. Keep out of reach from children.

Product color and appearance may vary from that shown on packaging.
2019 InvenTel Products, LLC. All Rights Reserved.



Made in China
Distributed by InvenTel
Products, LLC.
200 Forge Way, Suite 1,



- 1. ON/OFF key 2. Mode key 3. Infrared lamp 4. LED indicator 5. Ultra wide angle
- 6. TF card port 7. Mini USB port 8. Rest port 9. Sling

Product features

- Full HD images
- Portable camera, easy to carry around
- HD functionality in low light
- 12MP(4032X3024) Picture Quality
- Motion - detecting video
- USB 2.0 interface
- Supports up to 64GB memory cards
- Rechargeable lithium battery allows for up to 60 minutes of use

Operation Instruction

Charging:

The Cube Cam comes with a built-in rechargeable lithium battery, which must be charged before the first use, and can be charged in the following way:

- 1) Use the USB charger and plug into your computer.
- 2) The camera can be used during charging if connected to a 5V charger or 220V. Both the blue and red LEDs will be lit during charging.
- 3) When charging is done, the red LED will turn off and the blue LED will stay on.

Please Note:

1. When the battery life is insufficient, or the memory card is full, the red and blue light will flash for 5 seconds, save the video, and automatically shut down.
2. If the camera is missing a memory card, the red and blue lights will flash for 5 seconds then shut down.
3. The camera will automatically shut down after 1 minute if the camera is in standby mode.

Video Recording:

Click the ON/OFF button to power on, the blue light will turn on to signal the camera is in standby mode. Click the ON/OFF button once more to start recording. The blue LED will flash 3 times then go out. The video recordings will automatically be saved every 5 minutes. In order to stop recording, press the ON/OFF button again.

• Motion Detecting Video Recording

- To activate Motion Detecting Video, the camera must be in standby mode. Press and hold the MODE button for 3 seconds. The camera will then be in motion detecting mode.
- If motion is detected, the video recording will start automatically, with red and blue LEDs flashing at the same time. The video recording will automatically save every 5 minutes.

• Photo

- Press the ON/OFF button to turn on the camera - the blue LED will light up. Press the MODE button twice to enter the photo mode.
- the red LED will stay lit. To take a picture, press the ON/OFF button once
- the red LED will flash once when your picture is taken.

• Night light

- Press the ON/OFF button to turn the camera on. Press and hold the ON/OFF button for 2 seconds - the red LED will flash twice to indicate that night illumination is on. To turn off the night illumination, press and hold the ON/OFF button for 2 seconds and the red LED will flash three times to indicate that the night illumination is turned off.

• Shutdown

- To turn off the Cube Cam, press and hold the ON/OFF button for 6 seconds. The camera will automatically shut off after 1 minute of being in standby mode.

• Viewing files

- Connect the shut off camera to the computer; after a few seconds it will automatically be detected as a removable disk. The blue LED light will indicate the transfer of information, and the red LED will indicate the charging of the built-in battery.



• Setting the date and time

Connect the mini camera to the computer. Setting the time is done by creating a text file named «TIMERSET.txt» in the root directory of the device's memory card, with the following content: «YYYYMMDDHHMMSS» «Y» (or «N», if you do not want the date and time stamp displayed on video files.) **Please note that the time should be entered in as military time.** (HHMMSS stands for Hours, Minutes, Seconds)

**For example, to set the date as 08/27/2017 and time as 02:00:03 PM (HHMMSS) you would enter «20170827140003 Y» after saving free file, disconnect the camera from the computer and turn it on.

• Parameters

- Video resolution: Hi-Definition
- Frame rate: 15, 30 frames per second
- Video file type: AVI
- Photo resolution: 4032x3024
- Photo file type: JPEG Viewing angle: 140°
- Night illumination: 6 IR LEDs (range of 5 meters, does not emit light)
- Motion (range is 5 meters)
- Records while charging
- 100 minutes (1 hour 40 minutes) in constant recording mode
- Average of 5 hours in motion sensor mode
- Picture mode: 12M
- Motion detection video



• Using the Table Stand & Body Clip

- Press the ends of the clip together to open the camera clip (Figure A).
- Align the grooves of the clip to the grooves of the stand. (Figure B).
- To attach the camera to the body clip, gently press the camera into the mounting grooves (Figure C).