

PRODUCT SERVICE AND SUPPORT

STOP!! IMPORTANT!!

PLEASE DO NOT RETURN THIS
ITEM TO THE STORE

PLEASE CALL US AT
973-531-4421

OR CONTACT US VIA EMAIL AT
CUSTOMERSERVICE@INVENTEL.TV

PLEASE READ MANUAL FULLY BEFORE USE!

100% SATISFACTION GUARANTEE!!

IF FOR ANY REASON YOU ARE NOT 100% SATISFIED
WITH YOUR PURCHASE PLEASE CONTACT US.
WE WILL BE HAPPY TO ASSIST YOU.



www.buycellphoneholder.com



Distributed by InvenTel Products, LLC
200 Forge Way, Suite 1
Rockaway, NJ 07866

© 2019 InvenTel Products, LLC. All Rights Reserved.

InvenTel Products reserves the right to provide you with the newest product available to date. Engineering enhancements are ongoing and may not be reflected in the pictures and specifications on this package.

1024190220

InvenTel Cell Phone Holder

USER MANUAL



FITS ANY AUTO
CUP HOLDER



6 INCH FLEXIBLE
GOOSE NECK



HOLDS PHONES
UP TO 3.5" WIDE



1. Hold the unit by the gooseneck and rotate the base till the three locking pads move outward.



2. Place the base in the cup holder when lock pads are close in diameter to the cup holder opening.



3. Lock the base by turning the cap clockwise in the direction of the arrow pointing to "lock".



4. Bend the gooseneck into any desired position.



5. Unlock the nut and tilt the phone cradle into a desired angle.



6. Squeeze the quick-release button to open the clamps.



7. Place a cell phone on the cradle and close the clamps. Be careful not to pinch your fingers.



8. Plug a charging cord into the bottom of the cell phone and you are ready to go.

Warning: Never install the holder or interact with your phone while driving.

Caution: Always unlock the cradle nut when adjusting the cell phone angle.