




Includes:




Asst no. 80890 6+


PLEASE FOLLOW INFLATION INSTRUCTIONS EXACTLY TO PROPERLY INFLATE YOUR WUBBLE BALL




1. Apply petroleum jelly to valve. (Cotton swab not included.)





2. Insert nozzle completely into valve.



3. Attach nozzle to pump and switch on.



4. Once inflated to your desired size (less than 3 feet), remove nozzle and make sure valve remains inside your Wubble.



1. Peel backing off patch. 2. Apply patch with hole in center so it is sealed equally all around. 3. Squeeze firmly to ensure a total seal to your ball.

IMPORTANT


The pump will automatically switch off after 15 minutes of continuous use. If the auto-shutoff activates, you have to turn the pump switch off, then on again to use it. If the pump does not function when switched on again, this indicates low battery power. Please replace with fresh batteries and start again.

Battery information:

4 "AA" size (1.5 V) batteries (not included) are needed to operate your Wubble pump. Adult supervision is required while installing and replacing batteries. Open the battery compartment underneath the pump, position the batteries inside, and close the compartment. Use the on/off switch to operate the device.

Battery safety:

- Different types of batteries or new and used batteries are not to be mixed.
Keep packaging for reference as it contains important information.
Only batteries of the same and equivalent type are to be used.
Batteries are to be inserted with the correct polarity.
Exhausted batteries are to be removed from toy.
Supply terminals should not be short-circuited.
Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.



Lifetime Replacement Guarantee

IMPORTANT: PLEASE DO NOT RETURN YOUR WUBBLE BALL TO THE STORE

If you pop your Wubble accidentally, we are happy to replace it for just \$6.99 to cover postage and handling.

Just go to http://guarantee.wubbleball.com

For all other product issues or questions, please contact customer service by email at help@wubbleball.com or call us at 888-425-9113. Please note that our customer service hours are from 9:00am to 5:00pm EST Monday through Friday. For a quicker response, email is best.

www.WubbleBall.com

© and © 2016 NSI International, Inc., and NSI Products (HK) Limited. All Rights Reserved. Made in China. Printed in China. Designed and engineered in U.S.A. Patented. Other Worldwide Patents Pending. Colors and contents may vary. This product contains small parts which are not suitable for children under 3 years old. Manufactured by NSI International, Inc. New York, NY 10010 and NSI Products (HK) Limited, Hong Kong.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.